

FLOORS @ WORK

Do's & Don'ts for Looselay & Aqua-Commercial Vinyl

- ✓ **DO** Place a natural or colorfast mat at outside entries to catch tracked-in dirt and moisture.
- ✓ **DO** Prevent indentations with felt floor protectors on chairs and furniture.
- ✓ **DO** Immediately wipe up spill or wet feet with a cloth or sponge.
- ✓ **DO** Trim the nails of pets, if not trimmed, it will cause the permanent damage.
- ✓ **DO** Wear shoes with soft soles. High heels can be disastrous for your vinyl floor.
- ✓ **DO** Allow the floor to acclimatize to room temperature for at least 48 hours before installation.

- ☒ **DO NOT** Use soap-based detergents or “mop and shine” products, which may leave a dull film.
- ☒ **DO NOT** Wax your floor.
- ☒ **DO NOT** Use abrasive cleaners or steel wool, which can leave scratches.
- ☒ **DO NOT** Install finishing trims too tight to the floor. You should be able to slide a sheet of paper between the two.
- ☒ **DO NOT** Drag & place heavy items like furniture and large appliances on your vinyl floor without using protective “Feet”. This will prevent unsightly marks, scratches, and damage.
- ☒ **DO NOT** Drench your vinyl floor. Water could penetrate the edges and corners of the room and destroy the glue bond it has been secured down with. This can result in the corners of the floor becoming loose and curling.
- ☒ **DO NOT** Use additional underpad.
- ☒ **DO NOT** Continue to the second row before making sure your first row is straight.
- ☒ **DO NOT** install vinyl flooring where there is direct sunlight.

Note: -If any instruction from the list above is not followed, Warranty will be voided.