

## LAMINATES

NAF Laminates are especially designed to endure wear resulting of normal use for many years. While we ensure that we manufacture the highest quality flooring for you and stand behind our products by offering you a 30-year limited residential warranty [for terms and conditions, please refer to Warranty guidelines], you are solely responsible for maintaining and caring for your floors to ensure that they will remain beautiful for the long term.

Please read below a few general tips on how to keep your floors looking their best.

## Care & Maintenance



- The room's ideal relative air humidity is 35-55% at 20°C (68° F)
- Using a room humidifier is recommended as a solution to prevent separations and minor gaps in the flooring joints. This is caused by increased heating during cold periods which may lower the indoor air humidity to the point the floors are prone to dry out.



- Use a vacuum or dry mop to clean flooring on regular intervals.
- A NAF recommended cleaner can also be used with a well wrung damp cloth.
- Refrain from using large amounts of water. Be sure to clean up any liquid spillage immediately.



- Use felt pads or area rugs to avoid marking from furniture legs.
- Using carpets and rugs at entry points will absorb and protect from sand and dirt.
- If pets are in the household, trim and maintain their nails regularly.