

✓ **SPC and WPC FLOORING – QUICK INSTALLATION CHECKLIST**

For AquaPlus, AquaSelect, AquaTile, Classic Collection, Royal Flooring Solutions, Aqua Platinum, AquaWood

📦 *To be included inside every box*

🔒 **IMPORTANT NOTICE**

This product must be installed according to manufacturer instructions and industry standards. Improper installation or failure to meet required site conditions will void warranty.

Do not install if the product appears damaged, defective, or if jobsite conditions are not suitable. **Contact your retailer immediately.**

The **property owner is responsible** for inspecting the flooring and confirming satisfaction **before installation begins.**

✓ **ESSENTIAL INSTALLATION REQUIREMENTS**

- **Acclimation:** Minimum **48-72 hours**, flat in installation area, HVAC must be running
- **Temperature:** Maintain between **18–29°C (65–85°F)** before, during, and after installation
- **Humidity:** Maintain between **40–70% RH** year-round
- **Subfloor:** Must be clean, dry, stable, and level
(Maximum **2mm over 2m** or **3/16” over 10 ft**)
- **Moisture Barrier:** Required **over concrete** slabs
→ **If the product has an attached pad, do not use additional underlayment — this will void the warranty.**
- **Expansion Gaps:** Leave **8–12mm** at all walls, columns, doorways, pipes, etc.
- **Transition Pieces:** Required if installing more than **36 ft in length** or **30 ft in width** in one continuous area
- **Do Not Install:** Under anything heavy such as cabinets, kitchen islands, or built-in furniture
- **Cutting:** Use **score-and-snap** or an SPC-approved cutter only
- **Floating Floor:** Do **not fasten** trims, moldings, or furniture through the floor

📷 **INSTALLATION BEST PRACTICES**

- Take **photos** of subfloor leveling, humidity/temperature readings, and expansion gaps
- Keep **2–3 spare planks** in original condition for any future repairs or evaluation
- Ensure **first row is straight** before continuing installation
- When installing near pipes, cut holes **12mm (½") larger** than pipe diameter
- Use **T-moldings** at doorways, long hallways, or any structural break between rooms
- Avoid **direct sunlight exposure** — use window coverings or UV film
- Follow **manufacturer radiant heat guidelines** if applicable

This checklist is subject to revision. Please ensure you are using the most current version by checking with your retailer or visiting floorsatwork.com. Floors@Work is not responsible for claims based on outdated documentation.

Version 1.0 – July 2025

 **CLEANING, CARE & PREVENTION TIPS**

DO:

- Place **colorfast mats** at entryways to trap dirt and moisture
- Use **felt pads** under furniture legs
- Wipe spills or wet feet **immediately**
- Keep **pet nails trimmed**
- Wear **soft-soled shoes**
- Maintain **consistent temperature and humidity** throughout the year

DO NOT:

- Use soap-based, wax, or abrasive cleaners
- Use **steel wool** or harsh chemicals
- Install trims/moldings too tightly (allow space for movement)
- Use **rolling chairs, gym equipment, or pool tables** on floor
- Slide or drag heavy furniture without protective feet
- Wet mop or flood the floor — excess water may damage seams or pad
- Install **additional underlayment** if pad is already attached
- Exceed 36 ft (length) or 30 ft (width) in one room without a **T-molding**
- Install in **direct sunlight** without UV protection

 **INSTALLATION = ACCEPTANCE**

Once installed, the product is considered accepted as-is.

Warranty will not cover issues related to visible defects, poor jobsite conditions, or failure to follow installation guidelines.

 **Full Instructions & Warranty Details**

 Visit: floorsatwork.com/installation